

Reusable food bag OEKO-TEX® cotton 30x40cm 19947201



Reduce the number of plastic bags in the supermarket by using your own food bag. This cotton bag with mesh is highly suitable for fruits and vegetables. Re-use it over and over again and when dirty, simply wash it at low temperatures (could shrink).

Colour



Brand: Toppoint Minimum quantity: 100 Unit(s) Diameter: 0.00 cm. Material: organic cotton Capacity: 0 ml Length: 30.00 cm. Width: 0.00 cm.

Height: 40.00 cm. Weight: 50.00 g.

Do you have a specific question or do you want more information about this item, please call 1800 800 801.